



PARTS LIST

No.	Parts No.	Description	Q'ty
1	7733F-01	Double Spanner	2
2	7733F-02	Collet Nut	1
3	7733F-03	6MM Collet	1
	7733F-03-1	3MM Collet	1
4	7733F-04	Housing Cap	1
5	7733F-05	Retainer	1
6	7733F-06	Spindle	1
7	7733F-07	Silencer	1
8	7733F-08	Ball Bearing	1
9	7733F-09	Front End Plate	1
10	7733F-10	Pin	2
11A	7733F-11	Cylinder (P.M.)	1
11B	7733F-11P	Cylinder (Steel)	1
12	7733F-12	Bearing Spacer	1
13A	7733F-13A	Rotor (Steel)	1
13B	7733F-13B	Rotor (Alloy)	1
14	7733F-14	Rotor Blade	4

No.	Parts No.	Description	Q'ty
15	7733F-15	Rear End Plate	1
16	7733F-16	Ball Bearing	1
17	7733F-17	Housing Cover	1
18	7733F-18	Motor Housing	1
19A	7733F-19A	Throttle Lever	1
19B	7733F-19B	Safety Lever	1
20	7733F-20	Lever Pin	1
21	7733F-21	Valve	1
21P	7733F-21P	O-Ring	1
22	7733F-22	Throttle Valve	1
22P	7733F-22P	O-Ring	1
23	7733F-23	O-Ring	1
24	7733F-24	Spring	1
25	7733F-25	Air Regulator	1
26	7733F-26	O-Ring	1
27	7733F-27	O-Ring	1
28	7733F-28	Valve Screw	1

ST-7733F(FM)-P-0412A-LW