



Index No.	Parts No.	Description	Index No.	Parts No.	Description
1	52-522501	Motor Housing	22	53222	Spindle
2	40337	Lever Pin (3x18L)	23	532223E	Ext.Housing
3	52-522503	Air Inlet	24	51224	Collet
4	52-522504	Throttle Lever	25	52225	Collet Nut
5	52-522505	Valve Shaft	26	532226E	Front Cap
6	52-522506	Deflector	27	52227	Spanner (2)
7	OR00705105	O-Ring (3) (7.5x1.5)	28	53226E	Washer
8	522208	Spring	29	52-522541	Fixed Shaft
9	70109	O-Ring (9.8x1.9)	30	53230E	Tension Shaft
10	52-522510	Valve Screw	31	40145	Steel Ball (1/8")
11	52236	O-Ring (10.5x1)	32	30107	O-Ring (3.8x1.9)
12	52212	Rotor Spacer	33	52-522553	Grip
13	052213	Ball Bearing (696ZZ)	34	522236	Bushing
14	52214	Rear End Plate	35	OR02105105	O-Ring (21.5x1.5)
15	52215	Rotor	36	51540	Safety Bar
16	52216	Vane (4)	37	522212	Spring
17	30117	Spring Pin (2) (1.5x6)	38	52245	Steel Ball (3/32")
18	52218	Cylinder	39	522240	Throttle Valve
19	52219	Front End Plate	46	522243	Washer
20	030120	Ball Bearing (2) (608ZZ)	51	522250	Damping Material
21	522220	Spring Pin (2x15L)			