



Index No.	Parts No.	Description	Index No.	Parts No.	Description
1	73103	Air Inlet	19	30118	Cylinder
2	73108	Spring	20	600419-12	Front Plate
3	75-725146	Valve Stem	21	030120	Ball Bearing (608ZZ)
5	600145	Rubber Spacer	22	600108	Spacer
7	40309	Screw (M3x8L)	23	600422	Internal Gear
8	600107	Diffuser	24	600423	Planet Gear (3)
9	82202	Pin (2.5x25.8)	25	30124	Pin (3) (4x13.8L)
10	600101	Motor Housing	26	600426	Work Spindle
11	72831	O-Ring (12.42x1.78)	27	073434	Ball Bearing (2) (6200Z)
12	600104	Trigger	28	600432	Clamp Nut
13	600106	Air Regulator	29	72529	Spacer
14	030113	Ball Bearing (626zz)	30	600110	Rubber Grip
15	30114	Rear Plate	31	600327V-31	Velcro Pad (3")
16	600415	Rotor	32	51228	Spanner
17	70616	Rotor Blades (4)	33	600425	Bushing (3)
18	30117	Spring Pin (1.5x6)	34	OR02607108	O-Ring (26.7x1.78)

6004-0001