



PARTS LIST

No.	Parts No.	Description	Q'ty
1	TF701-01	Throttle Leve	1
2	TF701-02	Lever Pin	1
3	TF701-03	Valve Pin	1
4	TF701-04	Valve Bod	1
5	TF701-05	O-Rin	2
6	TF701-06	Throttle Valve	1
7	TF701-07	Valve S rin	1
8	TF701-08	Retainin Rin	1
9	TF701-09	O-Rin	2
10	TF701-10	Re ulato	1
11	TF701-11	Deflecto	1
12	TF701-12	ir Inlet	1
13	TF701-13	Deflector Screw	2
18	TF701-18	Motor Housin	1
19	TF701-19	Screw	1
20	TF701-20	Ball Bearin	1
21	TF701-21	Front Plate	1
22	TF701-22	Roto	1
23	TF701-23	Vane	4
24	TF701-24	C linde	1
25	TF701-25	Rear Plate	1
26	TF701-26	Ball Bearin	1
27	TF701-27	C linder Pin	1

No.	Parts No.	Description	Q'ty
28	TF701-28	O-Rin	1
29	TF701-29	C linder Pin	4
30	TF701-30	Motor Gasket	1
31	TF701-31	Motor Retainer	1
32	TF701-32	Screw	4
33	TF701-33	Washe	4
34	TF701-34	Rubber Support	4
35	TF701-35	Washe	4
36	TF701-36	Cap Screw	4
37	TF701-37	Crank Shaft	1
38	TF701-38	Ke	1
39	TF701-39	Lower Wei ht	1
40	TF701-40	Ca Screw	1
41	TF701-41	Nut	4
42	TF701-42	Washe	4
43	TF701-43	Shoe Bearin Housin	1
44	TF701-44	Ball Bearin	1
45	TF701-45	Shoe	1
46	TF701-46	Screw	4
47	TF701-47	Rubber Pad	1
48	TF701-48	Washe	4
49	TF701-49	Screw	4

TF-701-P-0907A-T2