



Index No.	Parts No.	Description	Index No.	Parts No.	Description
1	73103	Air Inlet	19	30118	Cylinder
2	73108	Spring	20	61012	Rotor Bush
3	75-725146	Valve Stem	21	600119-12	Front Plate
5	600145	Rubber Spacer	22	030120	Ball Bearing (608zz)
7	40309	Screw (M3x8L)	23	600312	Connector
8	600107	Diffuser	24	600108	Spacer
9	82202	Pin (2.5x25.8)	25	600313	Motor Lock Nut
10	600101	Motor Housing	26	600322	Counter Balance
11	72831	O-Ring (12.42x1.78)	27	600323	Nut
12	600104	Trigger	28	030120-12	Ball Bearing (608RS)
13	600106	Air Regulator	29	52827	Stop Ring (RTW-22)
14	030113	Ball Bearing (626zz)	30	600321	Guard
15	30114	Rear Plate	31	600110	Rubber Grip
16	600115	Rotor	32	600324	Key
17	70616	Rotor Blades (4)	33	600327V-31	Pad (3")
18	30117	Spring Pin (1.5x6)	34	OR02607108	O-Ring (26.7x1.78)

6003VG5-0003