





MODELO CS-48

ATORNILLADOR RECTO 1,700 RPM

PARTS LIST

No.	Parts No.	Description	Q'ty
1	5A6029	End Housing	1
1-1	2S3010	Inner Bushing	1
1-2	2S6001	Outer Bushing	1
2	2U6001	Switch Bushing	1
3	7S2108	Set Screw And Washer	1
4	6N5113	Spring	1
5	2S5020	Valve Pin	1
6	7Q6112	Valve O-Ring	1
7	6S2030	Screw	1
8	7S2113	Screw	1
9	6S2030-1	Screw	1
10	7S2113	Screw	1
11	2Q2003	O Ring	1
11-1	2L6021	Switch	1
12	2P3021	Silencer	1
13	2A6001	Exhaust Deflector	1
14	2P3010	Silencer	1
15	5A6042	Center Housing	1
16	7Q2011	Valve O-Ring	1
16-1	6N5006	Spring	1
17	2P6002	Valve	1
18	7S5001	Ball Bearing	1
19	1S6001	End Plate	1
20	1P6005	Cylinder	1
21	1S6048	6T Rotor [CS-48]	1
22	1S6047	10T Rotor [CS-58]	1
23	1P6051	Blade	6
24	1P6062	Front Plate	1
24-1	7S2102	Ball	36
25	7S2002	Ball Bearing	1
26	6N2020	C Ring [CS-58]	1
27	1S3050	Connect [CS-48]	1
28	1P2271	21T Main Gear [CS-48]	1
29	1P2102	10T Plant Gear [CS-48]	7
29-1	1P2101	15T Plant Gear [CS-58]	4
30	1P6294	Third Gear Cage [CS-48]	1

No.	Parts No.	Description	Q'ty
30-1	1P3280	Fifth Gear Cage [CS-58]	1
31	1G6271	21T Main Gear [CS-48]	1
31-1	1G6090	14T Main Gear [CS-58]	1
32	1P6111	10T Plant Gear [CS-48]	7
32-1	1P6130	14T Plant Gear [CS-58]	4
33	1P6295	Third Gear Cage [CS-48]	1
33-1	1P6288-1	Fourth Gear Cage [CS-58]	1
34	1S3157	Internal Gear	1
35	7S2010	Ball Bearing	2
36	5A5354	Clutch Housing	1
37	3S5040	Anvil	1
38	6N2081	C Ring	1
39	7S2105	Ball	3
40	2S5233	Washer	1
41	5N5210	Torque Spring [CS-48]	1
41-1	6N5211	Torque Spring [CS-58]	1
42	3S3221	Regulation Washer	1
43	3A6301	Torque Ring	1
44	6N3301	C Ring	1
45	7S3107	Ball	1
46	6N2110	Spring	1
47	5S2001	Bit Slide Sleeve	1
48	6N2001	C Ring	1
49	7Q6100	O Ring	1
50	7S2103	Ball	1
51	6N2105	Spring	1
52	5L6102	Lever	1
53	5A2002	Lever Set	1
54	7S2202	Roll pin	1
55	2Q5001	O Ring	1
55-1	7L0002	Washer	1
56	2S2010	Air Inlet Bushing [PT]	1
56-1	2S6005	Air Inlet Bushing [PS]	1
56-2	2S2007	Air Inlet Bushing [NPT]	1
57	2U2002	Air House Nipple	1
58	5N2005	Suspension Ring	1

P-0805F-MI