



#### PARTS LIST

No.	Parts No.	Description	Q't
1	4467-01	Hook	1
2	4467-02	Air Inlet 18NPT	1
2B	4467-02B	Air Inlet 19NPT	1
3	4467-03	O-Ring P8x1.5	2
4	4467-04	Muffler	1
5	4467-05	Pin Φ3x26	1
6	4467-06	Screw	1
8	4467-08	Switch Lever	1
9	4467-09	Handle	1
10	4467-10	O-Ring	1
11	4467-11	Brush	1
12	4467-12	Bushin	1
13	4467-13	O-Ring P3.5x1.5	1
14	4467-14	Valve Rod	1
15	4467-15	O-Ring P4x1.9 ST-4467A	4
16	4467-16	Spring	1
18	4467-18	Ring	1
19	4467-19	Screw	1
20	4467-20	Bushin	1
21	4467-21	Spring	1
22	4467-22	Revers Valve	1
23	4467-23	Ball Bearing 696	1
24	4467-24	Face Plate	1
25	4467-25	Pin Φ 2x18	1
26	4467-26	Cylinder	1
27	4467-27	Pin Φ2x6	1
28	4467-28	Rotor Blade	7
29	4467-29	Rotor	1
30	4467-30	Front Plate	1
31	4467-31	O-Ring P29.87x1.8	1
32	4467-32	Ball Bearing R6	1

No.	Parts No.	Description	Q't
33	4467-33	Bolt	1
34	4467-34	Washer	1
35	4467-35	Hammer Cam	1
36	4467-36	Hammer Case	1
37	4467-37	Hammer	2
38	4467-38	Pin Φ4.5x29	2
39	4467-39	Nut	1
40	4467-40	Ring	1
41	4467-41	Washer	1
42	4467-42	Bushin	1
43	4467-43	Bushin	1
44	4467-44	Steering Wheel	2
45	4467-45	Steering Wheel Φ16mm	1
46	4467-46	L Head	1
47	4467-47	Driving Rod	1
48	4467-48	Internal Case	1
49	4467-49	Bushin	1
50	4467-50	Pin Φ6x40	1
51	4467-51	Gear Of Anvil SQ ST-4467A	1
	4467-51	Gear Of Anvil HEX ST-4467	1
52	4467-52	Bushin	1
53	4467-53	Washer	3
54	4467-54	Bushin	1
55	4467-55	Spring	1
56B	4467-56B	O-Ring ST-4467	1
57B	4467-57B	Iron Ball Φ1/8" ST-4467	1
58	4467-58	Oil Seal	1
59	4467-59	O-Ring P34.6x2.62	1
60	4467-60	O-Ring P37.82x1.78	1
61	4467-61	Washer	1
62	4467-62	Retaining Ring ST-4467A	1