



### PARTS LIST

No.	Parts No.	Description	Q'ty
1	6657-01	Housing	1
1A	6657-01A	Ball, 6.35mm	1
2	6657-02	Pin, 3X27.8	1
5	6657-05	O-Ring, 3.9x2.25x2	1
7	6657-07	O-Ring, 3.5x1.5	1
8	6657-08	Valve Stem	1
9	6657-09	O-Ring, P14	3
10	6657-10	Valve Bushing	1
11	6657-11	Spring	1
12	6657-12	Trigger	1
13	6657-13	Set Screw, M4x4	1
14	6657-14	Ball Bearing, 696ZZ	1
15	6657-15	Set Screw, M3x12	1
16	6657-16	Rear End Plate	1
17	6657-17	O-Ring, 33.05x1.78	1
18	6657-18	Rotor Blades	5
19	6657-19	Rotor	1
20	6657-20	Cylinder	1
21	6657-21	Ball, 5	1
22	6657-22	Ball Bearing, 608ZZ	1
23	6657-23	Spring	1
24	6657-24	Clamp Nut	1
25	6657-25	Gear Case	1
26	6657-26	Gear Housing	1
27	6657-27	Spring	2
28	6657-28	Ball, 4	2
29	6657-29	Adjusting Nut	1
30	6657-30	Wave Washer, 6200	2
31	6657-31	Retaining Ring, S22	1
32	6657-32	Ball Bearing, R8	1

No.	Parts No.	Description	Q'ty
32	6657-32	Ball Bearing, R8	1
33	6657-33	Gear Case	1
34	6657-34	Gear	2
35	6657-35	Pin, 3x17.8	2
36	6657-36	Washer	1
37	6657-37	Ball Bearing, R6ZZ	1
38	6657-38	Internal Gear	1
39	6657-39	Bit Holder	1
40	6657-40	Set Screw, M5x5	1
41	6657-41	Set Screw, M4x6	1
42	6657-42	Lock attachment	1
43	6657-43	Spring	1
44	6657-44	Retainer	1
45	6657-45	Supporter	1
46	6657-46	Drill Bit, 8	1
46A	6657-46A	Drill Bit, 6.5	1
46B	6657-46B	Drill Bit, 10	1
47A	6657-47A	Lock Nut	1
48	6657-48	Retaining Ring	1
50	6657-50	Washer, 2"	1
50A	6657-50A	Washer, 3"	1
50B	6657-50B	Washer, 5.5"	1
51	6657-51	Screw, M4x8	1
52	6657-52	O-Ring, P18	1
53	6657-53	Muffler Nut	1
54	6657-54	Muffler	1
55	6657-55	Muffler Retainer	1
56	6657-56	Air Inlet	1
57	6657-57	Service Wrench, 2.5mm	1
58	6657-58	O-Ring	2