



Part_No	Description	Spec	Q'ty	Part_No	Description	Spec	Q'ty	Part_No	Description	Spec	Q'ty
FA0701	STOPPER		4	OB221A	O-RING	22×3	1	PH0401	COVER PLATE(A)		1
FA0901	PUSHER PIN		2	OB271A	O-RING	26.8×2.4	1	PH1201	FIXED PLATE		5
FA1001	PUSHER SPRING		2	OP010A	O-RING	P10	1	UE0101	BODY		1
FA1201	MAGAZINE RETAINER		1	OP012A	O-RING	P12	1	UE0201	CYLINDER CAP		1
FA1401	LATCH		1	OS030A	O-RING	S-30	1	UE0301	HEAD VALVE PISTON		1
FA2001	SPRING		1	PA1601	NOZZLE		1	UE0401	CAP SEAL		2
FA2101	WRENCH SET		1	PA1901	PIN		1	UE0501	EXHAUST CAP		1
FG1001	BAR		1	PA2001	END CAP		1	UE0601	PISTON STOP		1
FM0301W	DRIVER ASSY.		1	PA3901	PIN		1	UE0701	COMPRESSION SPRING		1
FM0701	MAIN PISTON		1	PC0601	SPRING		5	UE1001	BUMPER		1
KM0306	HEX.SOC.HD.BOLT	M3×0.5—6L	2	PC0701	PIN		1	UE1101W	TRIGGER VALVE ASSY.		1
KM0308	HEX.SOC.HD.BOLT	M3×0.5—8L	2	PE0602	SPACER		1	UE1201	COLLAR		1
KM0408	HEX.SOC.HD.BOLT	M4×0.7—8L	2	PF0102	DRIVER SET		1	UE1301	COMPRESSION SPRING		1
KM0506	HEX.SOC.HD.BOLT	M5×0.8—6L	2	PF0301	CYLINDER		1	UE1401	TRIGGER VALVE STEM		1
KM0520	HEX.SOC.HD.BOLT	M5×0.8—20L	3	PF0401	CAP		1	UE1501	SEAL		1
KM0535	HEX.SOC.HD.BOLT	M5×0.8—35L	4	PF0502	COVER PLATE(B)		1	UE1601	TRIGGER VALVE GUIDE		1
KR0412	BUTTON HD.BOLT	M4×0.7—12L	2	PF0603	GUIDE PLATE		1	UE1701	TRIGGER VALVE SEAT		1
OA003A	O-RING	ARP568-003	1	PF0701	MAGAZINE SEAT		1	UE1801	TRIGGER		1
OA004A	O-RING	ARP568-004	1	PF0801	MAGAZINE CAP		1	UH1301	TRIGGER STOP		1
OA120A	O-RING	ARP568-120	1	PF0901	PUSHER		1	YA0402	HEX BAR WRENCH	D4	1
OA126A	O-RING	ARP568-126	1	PF1001	FIXED PLATE SEAT		5	YE2501	E-RING	∅ 2.5	2
OA204B	O-RING	ARP568-204	1	PF1101	SUPPORT		1	YG0501	SPRING WASHER	∅ 5	2
▲ OB181H	O-RING	17.7×3.0	1	PF1201	STOP PLATE		1	YL0508	LOCK NUT	M5×0.8	1

¡ i If you need to order parts, please mark both Parts No. and Description. ¡ i

200906 H