



6/23/06

Index NO.	PART NO.	DESCRIPTION
1D	107163	3/16" Nosepiece
2	02115A	Head
3	10709	Jaw Housing
4	107B08	Jaw (2)
5	107B07	Jaw Pusher
6	02105	Spring
7	10548	O-Ring Seal
8	02106	Jaw Housing Coupler
9	02104	Nut
10	11520	X-Ring Seal (4)
11	11558	Ring Washer (4)
12	02102	Hydraulic Seciton
13	02171	Oil Plug
14	021510	Hydraulic Plunger
15	11501	O-Ring Seal
16	11549	O-Ring Washer
17	02152	Return Spring
18	02153	Return Spring
19	02127	O-Ring Seal
20	02159	Hanging Ring
21	02110	Screw Plug
22	02123	Piston Disc
23	02124	Air Piston Ring
24	20412	O-Ring Seal
25	76527	Spring Washer
26	10427	Piston Head Lock Screw

Index NO.	PART NO.	DESCRIPTION
27	02122	Plunger Rod
28	02130	Damping Ring
29	25022	O-Ring Seal
30	02157	Screw Plug
31	02101	Air Cylinder
32	02116	O-Ring Seal
33	10431	O-Ring Seal
34	02103	Air Cylinder Cap
35	02197	O-Ring Seal
36	02139	Valve Tube
37	11541	Valve Spring
38	11560	O-Ring Seal
39	10442	Valve Plate
40	10544	Spring
41	10550	Screw Plug
42	02121	Lock Nut
43	02167	Pin
44	02134	Trigger Lever
45	02168	Pin
46	02169	Pin
47	N2.5x6	Pin
48	02133	Trigger Rod
49	02172	Set Screw
51	02138	Trigger
58	02170	O-Ring Seal

Gauge of Wrench 50 is a 2-13/16" (72 mm) measure. Use as shown for correct adjustment on Jaw Assembly.

*** ACCESSORIES ***			
Index.	Part No.	Description	
1A	106160	3/32" Nosepiece	
1B	107161	1/8" Nosepiece	
1C	107162	5/32" Nosepiece	
4	107B08	Jaws (2)	
50	10647	Wrench	
	10459	14/17mm Wrench(14S17)	

*** OPTIONAL ACCESSORIES ***			
59	#021470	Universal Joint kit	1SET