


AIXIA, S.A.

Sasikoa, nº 12
Tfno: 946 201 708 Fax: 946 201 680
48200 DURANGO (Bizkaia)



PARTS LIST

- | | | | |
|----|--|----|--------------------------------------|
| 1 | Spring Canister (1) | 20 | Bolt (2) |
| 2 | Drum (air inlet side) (1) | 21 | Washer (1) |
| 3 | Drum (mounting bracket side) (1) | 22 | Nut (1) |
| 4 | Mounting Bracket (1) | 23 | Washer (3) |
| 5 | Guide Arm (1) | 24 | Bolt (3) |
| 6a | Air Inlet Valve Body (1)
(includes 2-pc. O-rings) | 25 | Nut (2) |
| 6b | Air Inlet Valve Swivel Collar (1) | 26 | Lock Nut (3) |
| 7 | Hose (1) | 27 | Roller Guide
Bracket Assembly (1) |
| 8 | Spring Hose Guard (1) | 28 | Hose Stopper Assembly (1) |
| 9 | Hub Bearing Assembly (1) | 29 | Ratchet Locking Gear (2) |
| 10 | Bolt (1) | 30 | Spacing Washer (1) |
| 11 | Locking Cam (1) | 31 | Retaining Ring (1) |
| 12 | Spring (1) | 32 | Bolt (4) |
| 13 | Axle (1) | 33 | Lock Washer (4) |
| 14 | Lock Washer (1) | 34 | Setscrew (1) |
| 15 | Nut (1) | 35 | Spacing Washer (1) |
| 16 | Bolt (3) | 36 | Nut (4) |
| 17 | Nut (7) | 37 | Spacing Washer (1) |
| 18 | Clamp (1) | 38 | Pin (1) |
| 19 | Clamp (1) | | |