



PARTS LIST

No.	Parts No.	Description	Q'ty
1	SA5500-01	Body	1
2	SA5500-02	Base	1
3	SA5500-03	O-Ring	1
4	SA5500-04	Spring	1
5	SA5500-05	Valve Stem	1
6	SA5500-06	O-Ring	1
7	SA5500-07	O-Ring	1
8	SA5500-08	Nozzle	1
9	SA5500-09	Steel Tube	1
10	SA5500-10	Alum Tube	1
11	SA5500-11	Nut	1
12	SA5500-12	Nozzle(Outer)	1
13	SA5500-13	Nozzle	1
14	SA5500-14	Packing	1
15	SA5500-15	Tube	1
16	SA5500-16	Cup	1
17	SA5500-17	Inlet Fitting	1

SA-5500(P)-P-0906B-LC