



PARTS LIST

No.	Parts No.	Description	Q'ty
1	2201-01	Plug-Throttle Valve [1/2"PT]	1
2	2201-02	Spring-Throttle Valve	1
3	2201-03	Valve-Throttle	1
4	2201-04	Bushing-Throttle Valve	1
5	2201-05	"O" Ring	1
6	2201-06	Pin-Push	1
7	2201-07	Bushing-Pin Push	1
9	2201-09	Bushing-Permanent	1
10	2201-10	Pin-Throttle Lever	1
11	2201-11	Lever-Throttle	1
12	2201-12	Handle	1
15	2201-15	Lid-Upper Valve Case	1
16	2201-16	Valve	1
17	2201-17	Case-Valve	1
18	2201-18	Lid-Lower Valve Case	1
19	2201-19	Pin-Stop	1

No.	Parts No.	Description	Q'ty
20	2201-20	Pin-Bowel [7.8*22.5]	2
22	2201-22	Piston For 1" & 2"	1
	2203-22	Piston For 3"	1
	2204-22	Piston For 4"	1
23	2201-23	Cylinder For 1"	1
	2202-23	Cylinder For 2"	1
	2203-23	Cylinder For 3"	1
	2204-23	Cylinder For 4"	1
27	2201-27	Lock	1
28	2201-28	Shield-Lock	1
31	2201-31	Sleeve-Retainer	1
34	2201-34	Spring-Lockcoil	1
35	2201-35	Bushing-Cylinder [R]	1
36	2201-36	Bushing-Cylinder [H]	1
37	2201-37	Lock	1
38	2201-38	Handle	1

ST-2201~4R(H)-P-0409A-FY