



### PARTS LIST

No.	Parts No.	Description	Q'ty
1	C580-01	Oil Seal	1
2	C580-02	Screw	2
3	C580-03	D-Handle	1
4	C580-04	O-Ring	1
5	C580-05	Anvil Collar	1
6	C580-06A	1" Dr. 2" Anvil [ST-C580]	1
	C580-06B	1" Dr. 6" Anvil [ST-C580-6]	1
7	C580-07	Hammer Pin	2
8	C580-08	Hammer Cage	1
9	C580-09	Washer	1
10	C580-10	Front Gasket	1
11	C580-11	Motor Housing	1
12	C580-12	Ball Bearing	1
13	C580-13	O-Ring	1
14	C580-14	Front Plate	1
15	C580-15	Rotor	1
16	C580-16	Spring Pin	1
17	C580-17	Cylinder	1
18	C580-18	Spring Pin	1
19	C580-19	Ball Bearing	1
20	C580-20	Reverse Lever	1
21A	C580-21A	Steel Ball	1

No.	Parts No.	Description	Q'ty
22	C580-22	Spring	1
23	C580-23	O-Ring	1
24	C580-24	O-Ring	1
25	C580-25	Rear Gasket	1
26	C580-26	Rear Cover	1
27	C580-27	Screw	4
28	C580-28	Hammer Case	1
29	C580-29	Bushing	1
30	C580-30	Hammer Dog	2
31	C580-31	Trigger	1
32	C580-32	O-Ring	1
33	C580-33	Retainer	1
34	C580-34	Valve Stem	1
35	C580-35	Spring	1
36	C580-36	Exhaust Deflector	1
37	C580-37	Rubber Cover	1
38	C580-38	Washer	1
39	C580-39	O-Ring	1
40	C580-40A	Hose Adaptor (PT19)	1
	C580-40B	Hose Adaptor (NPT18)	1
41	C580-41	Rotor Blade	6
42	C580-42	Muffler	1

ST-C580(-6)-P-1306E-YC