



PARTS LIST

No.	Parts No.	Descri tion	Q't
1	5245-01	Hammer Case Ass'y [Incl.: 42, 43, 59]	1
2	5245-02	Housin	1
3	5245-03	Motor Housin	1
4	5245-04	Tri er	1
5	5245-05	Lock Rin	1
6	5245-06	ir Inlet PT19	1
	5245-06B	ir Inlet NPT18	1
7	5245-07	O-Rin	1
8	5245-08	S rin	1
10	5245-10	Exhaust Deflector	1
11	5245-11	Motor Housin	1
12	5245-12	Bushin	1
13	5245-13	Throttle Valve Plun er	1
14	5245-14	O-Rin	1
16	5245-16	S rin Pin	1
17	5245-17	Reverse Knob	1
18	5245-18	Pin	1
19	5245-19	Gasket	1
20A	5245-20A	Throttle Valve Ass'y [Incl 20-1, 20-2]	1
21	5245-21	Screw	4
22	5245-22	O-Rin	1
23	5245-23	O-Rin	1
24	5245-24	Reverse Valve	1
25	5245-25	Pin	1
26	5245-26	S rin	1
27	5245-27	Bearin	1
28	5245-28	End Plate	1

No.	Parts No.	Descri tion	Q't
29	5245-29	S rin Pin	3
30	5245-30	C linder	1
31	5245-31	Rotor Blade	7
32	5245-32	Rotor	1
33	5245-33	End Plate	1
35	5245-35	Bearin	1
36	5245-36	Washer	1
37	5245-37	Hammer Pin	2
38	5245-38	Hammer Frame	1
39	5245-39	Hammer	1
40	5245-40	Bushin	1
41	5245-41	Work S indle	1
44	5245-44	Pin	1
45	5245-45	1/2" Ratchet Anvil Incl.: 09, 51	1
54	5235-54	3/8" Ratchet Anvil Incl.: 55, 56	1
46	5245-46	Retainer	1
47	5245-47	Thrust Washer	1
48	5245-48	Retainer	1
49	5245-49	O-Rin	1
50	5245-50	Throttle Valve Seat	1
52	5245-52	O-Rin	1
53	5245-53	O-Rin	1
57	5245-57	Needle Bearin	1
58	5245-58	Screw	2
60	5245-60	Gasket	1
5245-T		Tune-Up Kit [Incl. 7, 8, 9, 14, 19, 22, 23, , , , , , ,]	
5235-TK		Tune-Up Kit [Incl. 7, 8, 14, 19, 22, 23, 26, 31(7), 49, 52, 53, 55, 56, 60]	