



PARTS LIST

No.	Parts No.	Description	Q't
1A	5534-01A	Housing Assembly [Incl. 1A-1(3), 7, 37, 44]	1
1A-1	5534-01A-1	Heli-Coil	3
2A	5534-02A	Throttle Valve Seat	1
3A	5534-03A	Throttle Valve Assembly [Incl. 3A-1, 3A-2]	1
3A-1	5534-03A-1	Throttle Valve Pin	1
3A-2	5534-03A-2	Throttle Valve	1
4	5534-04	Spring	1
5	5534-05	Exhaust Deflector	1
6	5534-06	Air Inlet	1
7	5534-07	Grease Fitting	1
8	5534-08	O-Ring	2
9	5534-09	Reverse Valve	1
10	5534-10	Steel Ball	1
11	5534-11	Spring	1
12	5534-12	Reverse Valve Knob	1
13	5534-13	Screw	1
14A	5534-14A	Trigger Assembly [Incl. 15]	1
15	5534-15	Trigger Pin	1
16	5534-16	Gasket	1
17	5534-17	Retainer	1
18	5534-18	Ball Bearing	1
19	5534-19	Rear End Plate	1

No.	Parts No.	Description	Q't
20	5534-20	Rotor	1
20A	5534-20A	O-Ring	1
21	5534-21	Cylinder	1
22	5534-22	Rotor Blade	6
23	5534-23	Cylinder Dowel	1
24	5534-24	Front End Plate	1
25	5534-25	Ball Bearing	1
26	5534-26	Washer	1
27	5534-27	Gasket	1
28	5534-28	Hammer Frame	1
29	5534-29	Hammer	1
30	5534-30	Hammer Pin	2
31	5534-31	Standard Anvil [Incl. 35, 36]	1
32	5534-32	Bushing	1
33	5534-33	Hammer Case	1
34	5534-34	Screw	3
35	5534-35	O-Ring	1
36	5534-36	Socket Retainer	1
37	5534-37	Reverse Valve Bushing	1
44	5534-44	Reverse Valve Bushing Gear	1
49	5534-49	Muffler Element	1
TK	5534-TK	Tune-Up Kit [Incl. 4, 8(2), 10, 11, 16, 17, 18, 20A, 22(6), 25, 27, 35, 36, 49]	1

ST-5534-P-0908D-01