



Index No.	Parts No.	Description	Index No.	Parts No.	Description
1	50-520001	Motor Housing	24	52-520124	Spindle
2	50-520002	Decoration Ring	25	30102	Spring Pin (Ø3x24L)
3	50-520003	Air Inlet	26	40128-21	Spring Pin (Ø2x16L)
4	5J-842304	Throttle Lever	27	52-520027	Felt Oiler
5	50-520005	Valve Shaft	28	52-520028	Front Housing
6	70107	O-Ring (Ø4.8xØ1.9)	29	OR03105200	O-Ring (Ø31.5xØ2)
7	70123	O-Ring (Ø11.8xØ2.4)	30	40126	O-Ring (Ø35.5xØ2)
8	50-520008	Spring	31	50-520052	Grip
9	OR04000200	O-Ring (Ø40xØ2)	32	51541	Spring
10	50-520010	Plug	33	5J-842350	Safety Bar
11	50-520011	Diffuser	34	709112R	Snap Ring (ISTW-10)
12	5K-3011B11	Rotor Bushing	35	52-520035	Clamp Nut
13	0BK0709	Needle Bearing	36	070329	Ball Bearing (6002zz)
14	5K-3011B14	Rear End Plate	37	52-520030	Clamp Nut
15	50-520015	Rotor	*38	50-500228-11	Collect chuck (1/4")
16	5K-3011B16	Rotor Blade (4)		50-500228-13	Collect chuck (3mm)
17	030113	Ball Bearing (626zz)		50-500228-16	Collect chuck (6mm)
18	50-520B18	Cylinder		50-500228-18	Collect chuck (8mm)
19	52-520019	Front End Plate	39	72017	Spring Pin(3) (Ø2.5x6L)
20	52-520020	Connector Nut	40	51228	Spanner(2) (14mm,19mm)
21	051220	Ball Bearing (6000zz)	41	5G-321V30	Screw (M4x8L)
22	52-520022	Bevel Gear	42	50-500223	Collect Nut
23	52-520023	Bevel Gear	43	5L-520020	Muffler

*Optional Parts

52-5201-0001
52-5201-0003
52-5201-0006
52-5201-0008