



PARTS LIST

No.	Parts No.	Description	Q'ty
1	7732F-01	Valve Screw	1
2	7732F-02	Valve Screw O-Ring	1
3	7732F-03	Regulator O-Ring	1
4	7732F-04	Air Regulator	1
5	7732F-05	Throttle Valve Spring	1
6	7732F-06	Throttle Valve O-Ring	1
7	7732F-07	Throttle Valve	1
8	7732F-08	Motor Housing	1
9	7732F-09	Throttle Lever	1
10	7732F-10	Throttle Leve Pin	1
11	7732F-11	Rear Rotor Ball Bearing	1
12	7732F-12	Rear End Plate	1
13A	7732F-13A	Dowel Pin	1
14A	7732F-14A	Cylinder	1
15A	7732F-15A	Rotor	1
16	7732F-16	Rotor Blade	4

No.	Parts No.	Description	Q'ty
17	7732F-17	Rotor Collar	1
18	7732F-18	Throttle Valve Bushing	1
18P	7732F-18P	O-Ring	1
19	7732F-19	Front End Plate	1
20	7732F-20	Front Rotor Ball Bearing	1
21	7732F-21	Spindle	1
22	7732F-22	Exhaust Muffler	1
23	7732F-23	Lock Nut	1
24	7732F-24	Collet 1/4"	1
	7732F-24A	Collet 1/8"	1
	7732F-24B	Collet 6mm	1
	7732F-24C	Collet 3mm	1
25	7732F-25	Colle Nut	1
26	7732F-26	Housing Cap	1
27	7732F-27	Spanner Wrench (L)	1
27P	7732F-27P	Spanner Wrench (S)	1

P-0610B-LW