



### PARTS LIS.

No.	Parts No.	Description	Q'ty
1	7475H-01	Plug Screw	1
2	7475H-02	O-Ring	1
3	7475H-03	O-Ring	1
4	7475H-04	Air Regulator	1
5	7475H-05	Valve Spring	1
6	7475H-06	O-Ring	1
7	7475H-07	Valve Stem	1
8	7475H-08	O-Ring	1
9	7475H-09	Motor Housing	1
10	7475H-10	Valve Bushing	1
11	7475H-11	Muffler	1
13	7475H-13	Air Inlet	1
14	7475H-14	Lever	1
15	7475H-15	Lever Pin	1
16	7475H-16	Bearing	1
17	7475H-17	Bearing Plate	1
18	7475H-18	Locating Pin	1

No.	Parts No.	Description	Q'ty
19	7475H-19	Cylinder	1
20	7475H-20	Rotor	1
21	7475H-21	Rotor Blade	4
22	7475H-22	Rotor Collar	1
23-1	7475H-23-1	Steel Plate	1
23-2	7475H-23-2	Steel Plate	1
24	7475H-24	Bearing Plate	1
25	7475H-25	Ball	1
26	7475H-26	Bearing	1
27	7475H-27	Spindle	1
28	7475H-28	Lock Ring	1
29	7475H-29	Collet	1
30	7475H-30	Collet Nut	1
31	7475H-31	Housing Cap	1
32	7475H-32	Wrench (11mm & 13mm)	2
33	7475H-33	Locating Pin	1

ST-7475H(M)-P-0807B-TP